

Restore QuickScan® Mobile Default



Enter configuration



Set Radio Address



+

four digits for the QuickScan® Mobile Address (from 0000 to 1999).



0



1



2



3

Exit and Save configuration



Bind



---

**Disable Enter**

Enter Configuration



no terminator



Exit and Save Configuration



---

**Enable Enter**

Enter Configuration



one character terminator



Exit and Save Configuration

