

## Most Commonly Used Suffixes

This scan sheet will work for the following scanners

- Gryphon™ Imager
- Gryphon™ Laser
- Quickscan™ Imager
- Powerscan™ D7100 or BT7100

Scan any one of the barcodes below to program the desired suffix.

Tab Suffix



Enter (CR) Suffix



Disable Suffix

