

Symbol LS-2208 Configuration Sheet


1. Set All Defaults



2. Do Not Transmit UPC-A Check Digit



3. Do Not Transmit UPC-E Check Digit



4. Scan Options



5. <DATA> <SUFFIX>



6. Enter



7. IBM PC/AT & IBM PC Compatibles

